

link-layer-overhead

Syntax	link-layer-overhead <i>percent</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For AS PIC or MultiServices PIC link services IQ interfaces (lsq) only, configure the percentage of total bundle bandwidth to be set aside for link-layer overhead.
Options	<i>percent</i> —Percentage of total bundle bandwidth to be set aside for link-layer overhead. Range: 0 through 50 percent Default: 4 percent
Usage Guidelines	See the <i>JUNOS Services Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

