

## local-mac

---

<b>Syntax</b>	local-mac <i>mac-address</i> remote-mac <i>mac-address</i> ;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> map], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family llc2 redundancy-group <i>group-number</i> map]
<b>Release Information</b>	Statement introduced in JUNOS Release 7.5.
<b>Description</b>	For J-series Services Routers only. On Ethernet interfaces configured for DLSw, specify the local MAC address to be mapped to a remote destination MAC address.
<b>Options</b>	<i>mac-address</i> —MAC address. Specify the MAC address as six hexadecimal bytes in one of the following formats: <i>nnnn.nnnn.nnnn</i> or <i>nn:nn:nn:nn:nn:nn</i> . For example, 0011.2233.4455 or 00:11:22:33:44:55.
<b>Usage Guidelines</b>	See Configuring LLC2 Options.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	<i>JUNOS Services Interfaces Configuration Guide</i>

