

## mac-address

---

<b>Syntax</b>	<code>mac-address <i>mac-address</i>;</code>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> accept-source-mac], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> accept-source-mac]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	For Gigabit Ethernet IQ and Gigabit Ethernet PICs with SFPs (except the 10-port Gigabit Ethernet PIC and the built-in Gigabit Ethernet port on the M7i platform), specify a remote MAC address on which to count incoming and outgoing packets.
<b>Options</b>	<i>mac-address</i> —MAC address. Specify the MAC address as six hexadecimal bytes in one of the following formats: <i>nnnn.nnnn.nnnn</i> or <i>nn:nn:nn:nn:nn:nn</i> . For example, 0011.2233.4455 or 00:11:22:33:44:55.
<b>Usage Guidelines</b>	See Configuring Gigabit Ethernet Policers.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

