

maximum-helper-restart-time

Syntax	maximum-helper-restart-time <i>seconds</i>
Hierarchy Level	[edit protocols ancp]
Release Information	Statement introduced in JUNOS Release 9.4.
Description	Specify how long other router processes wait for ANCP to restart before considering it to be down.
Options	<i>seconds</i> —Number of seconds other processes wait for ANCP to restart. Range: 45 through 600 seconds Default: 45 seconds
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Configuring ANCP■ Specifying How Long Processes Wait for ANCP Restart to Complete

