

mode

Syntax	mode loose;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family (inet inet6) rpf-check], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family (inet inet6) rpf-check]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Check whether the packet has a source address with a corresponding prefix in the routing table. If a corresponding prefix is not found, unicast reverse path forwarding (RPF) loose mode does not accept the packet. Unlike strict mode, loose mode does not check whether the interface expects to receive a packet with a specific source address prefix.
Default	If you do not include this statement, unicast RPF is in strict mode.
Usage Guidelines	See Configuring Unicast RPF and Configuring Unicast RPF.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

