

modem-options

Syntax modem-options {
 dialin (console | routable);
 init-command-string *initialization-command-string*;
}

Hierarchy Level [edit interfaces umd0]

Release Information Statement introduced in JUNOS Release 8.2.

Description For J-series Services Routers, configure a USB port to act as a USB modem.

The remaining statement is explained separately.

Usage Guidelines See Specifying a USB Modem Interface on J-series Routers.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

