

## mrru

---

|                                 |  |
|---------------------------------|--|
| <b>Syntax</b>                   | mrru <i>bytes</i> ;  |
| <b>Hierarchy Level</b>          | [edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options],<br>[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> ],<br>[edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> ] |
| <b>Release Information</b>      | Statement introduced before JUNOS Release 7.4.   |
| <b>Description</b>              | For multilink, link services, voice services, and J-series Services Routers ISDN interfaces only, set the maximum received reconstructed unit (MRRU). The MRRU is similar to the MTU, but is specific to multilink interfaces.   |
| <b>Options</b>                  | <i>bytes</i> —MRRU size.<br><b>Range:</b> 1500 through 4500 bytes<br><b>Default:</b> 1500 bytes  |
| <b>Usage Guidelines</b>         | See Configuring ISDN Logical Interface Properties and the <i>JUNOS Services Interfaces Configuration Guide</i> .   |
| <b>Required Privilege Level</b> | interface—To view this statement in the configuration.<br>interface-control—To add this statement to the configuration.  |
| <b>Related Topics</b>           | mtu  |

