

## multicast-only

---

<b>Syntax</b>	multicast-only;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	Configure the unit and family so that it can transmit and receive multicast traffic only. You can configure this property on the IP family only.
<b>Usage Guidelines</b>	See Configuring the Protocol Family.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	tunnel, <i>JUNOS Services Interfaces Configuration Guide</i>

