

multilink-max-classes

Syntax	multilink-max-classes <i>number</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i>], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For Adaptive Services (AS) PIC link services IQ interfaces (lsq) only, configure the number of multilink classes to be negotiated when a link joins the bundle.
Options	<i>number</i> —The number of multilink classes to be negotiated when a link joins the bundle. Range: 1 through 8 Default: None
Usage Guidelines	See the <i>JUNOS Services Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	multipoint

