

n392

Syntax	n392 <i>number</i> ;
Hierarchy Level	[edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For link services and voices interfaces only, set the Frame Relay error threshold, in number of errors.
Options	number—Error threshold. Range: 1 through 10 Default: 3
Usage Guidelines	See the <i>JUNOS Services Interfaces Configuration Guide</i> .
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	n391, n393, timeslots, t392

