

## n393

---

<b>Syntax</b>	n393 <i>number</i> ;
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> mlfr-uni-nni-bundle-options]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	For link services and voices interfaces only, set the Frame Relay monitored event count.
<b>Options</b>	<i>number</i> —Number of event count. <b>Range:</b> 1 through 255 <b>Default:</b> 6
<b>Usage Guidelines</b>	See the <i>JUNOS Services Interfaces Configuration Guide</i> .
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	n391, n392, timeslots, t392

