

## nas-identifier

---

<b>Syntax</b>	nas-identifier <i>identifier-value</i> ;
<b>Hierarchy Level</b>	[edit access profile <i>profile-name</i> radius options]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.1.
<b>Description</b>	Configure the value for the client RADIUS attribute 32 (NAS-Identifier). This attribute is used for authentication and accounting requests.
<b>Options</b>	<i>identifier-value</i> —A string in the range from 1 through 64 characters.
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	■ <a href="#">Configuring RADIUS Server Parameters for Subscriber Access</a>

