

no-allowed-mac-log

Syntax	no-allowed-mac-log;
Hierarchy Level	[edit ethernet-switching-options secure-access-port interface (all <i>interface-name</i>)]
Release Information	Statement introduced in JUNOS Release 9.3 for EX-series switches.
Description	Specify that the switch is to create log messages when it receives packets from invalid MAC addresses on an interface that has been configured for particular (allowed) MAC addresses.
Default	Disabled.
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ allowed-mac■ Example: Configuring Port Security, with DHCP Snooping, DAI, MAC Limiting, and MAC Move Limiting, on an EX-series Switch■ Example: Configuring Allowed MAC Addresses to Protect the Switch from DHCP Snooping Database Alteration Attacks■ Example: Configuring MAC Limiting to Protect the Switch from DHCP Starvation Attacks■ Configuring MAC Limiting (CLI Procedure)■ Configuring MAC Limiting (J-Web Procedure)

