

no-arp

Syntax no-arp;

Hierarchy Level [edit forwarding-options dhcp-relay overrides],
[edit forwarding-options dhcp-relay group *group-name* overrides],
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay overrides],
[edit logical-systems *logical-system-name* forwarding-options dhcp-relay group *group-name* overrides],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* forwarding-options dhcp-relay overrides],
[edit logical-systems *logical-system-name* routing-instances *routing-instance-name* forwarding-options dhcp-relay group *group-name* overrides],
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay overrides],
[edit routing-instances *routing-instance-name* forwarding-options dhcp-relay group *group-name* overrides]

Release Information Statement introduced in JUNOS Release 9.3.

Description Turn off ARP table population in a distrusted environment.

Required Privilege Level interface—To view this statement in the configuration.
interface-control—To add this statement to the configuration.

Related Topics

- Extended DHCP Relay Agent Overview
- Overriding the Default DHCP Relay Configuration

