

## no-broadcast

---

**Syntax** no-broadcast;

**Hierarchy Level** [edit ethernet-switching-options storm-control interface (all | *interface-name*)]

**Release Information** Statement introduced in JUNOS Release 9.1 for EX-series switches.  
Statement deprecated in JUNOS Release 9.4 for EX-series switches.



**NOTE:** If you configure this statement, it has no effect. This statement has been deprecated and might be removed from future product releases.

---

**Description** For interfaces configured for storm control, disable broadcast traffic storm control on the interface.

**Default** When storm control is enabled on an interface, it is enabled for both unknown unicast traffic and broadcast traffic.

**Required Privilege Level** routing—To view this statement in the configuration.  
routing-control—To add this statement to the configuration.

**Related Topics**

- Example: Configuring Storm Control to Prevent Network Outages on EX-series Switches
- Understanding Storm Control on EX-series Switches

