

no-management-vlan

Syntax no-management-vlan;

Hierarchy Level [edit virtual-chassis member *member-id*]

Release Information Statement introduced in JUNOS Release 9.0 for EX-series switches.

Description Remove the specified member's out-of-band management port from the Virtual Management Ethernet (VME) global management VLAN of the Virtual Chassis configuration.

For a member that is functioning in a linecard role, you can use this configuration to reserve the member's management Ethernet port for local troubleshooting:

```
virtual-chassis {  
  member 2 {  
    no-management-vlan;  
  }  
}
```

You cannot configure the IP address for a local management Ethernet port using the CLI or the J-Web interface. To do this, you need to use the shell `ifconfig` command.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

- Related Topics**
- Example: Setting Up a Multimember Virtual Chassis Access Switch with a Default Configuration
 - Configuring the Virtual Management Ethernet Interface for Global Management of a Virtual Chassis (CLI Procedure)
 - Understanding Global Management of a Virtual Chassis Configuration

