

## periodic

---

**Syntax** `periodic interval;`

**Hierarchy Level** [edit interfaces `aex` aggregated-ether-options lacp]

**Release Information** Statement introduced in JUNOS Release 9.0 for EX-series switches.

**Description** Configure the interval for periodic transmission of LACP packets.

**Default** `fast`

**Options** *interval* —Interval at which to periodically transmit LACP packets:

- `fast`—Transmit packets every second. This is the default.
- `slow`—Transmit packets every 30 seconds.

**Required Privilege Level** `interface`—To view this statement in the configuration.  
`interface-control`—To add this statement to the configuration.

**Related Topics**

- Example: Configuring Aggregated Ethernet High-Speed Uplinks with LACP Between a Virtual Chassis Access Switch and a Virtual Chassis Distribution Switch
- Configuring Aggregated Ethernet LACP (CLI Procedure)
- Understanding Aggregated Ethernet Interfaces and LACP
- *JUNOS Software Network Interfaces Configuration Guide* at <http://www.juniper.net/techpubs/software/junos/junos95/index.html>

