

pic-type

Syntax	pic-type (atm1 atm2);
Hierarchy Level	[edit interfaces <i>at-fpc/pic/port</i> atm-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For ATM interfaces, configure the type of ATM PIC installed in your routing platform.
Options	atm1—ATM1 PIC atm2—ATM2 IQ PIC
Usage Guidelines	See Configuring the ATM PIC Type.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

