

pre-ietf-mode

| | |
|---------------------------------|--|
| Syntax | pre-ietf-mode |
| Hierarchy Level | [edit protocols ancp], [edit protocols ancp neighbor] |
| Release Information | Statement introduced in JUNOS Release 9.4. |
| Description | Configure ANCP to run in a mode that is backward compatible with Internet draft draft-ietf-ancp-protocol-00.txt, <i>Protocol for Access Node Control Mechanism in Broadband Networks</i> for all neighbors or for a specific neighbor. |
| Required Privilege Level | interface—To view this statement in the configuration. interface-control—To add this statement to the configuration. |
| Related Topics | <ul style="list-style-type: none">■ Configuring ANCP■ Configuring ANCP for Backward Compatibility■ Configuring ANCP Neighbors |

