

primary-vlan

Syntax primary-vlan *vlan-name*

Hierarchy Level [edit vlans *vlan-name*]

Release Information Statement introduced in JUNOS Release 9.3 for EX-series switches.
Statement updated with enhanced ? (CLI completion feature) functionality in JUNOS Release 9.5 for EX-series switches.

Description Configure the primary VLAN for this community VLAN. The primary VLAN must be tagged, and the community VLAN must be untagged.



TIP: To display a list of all configured VLANs on the system, including VLANs that are configured but not committed, type ? after **vlan** or **vlans** in your configuration mode command line. Note that only one VLAN is displayed for a VLAN range.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

Related Topics ■ Example: Configuring a Private VLAN on an EX-series Switch
 ■ Creating a Private VLAN (CLI Procedure)

