

request

Syntax	request (protect working);
Hierarchy Level	[edit interfaces <i>interface-name</i> sonet-options aps]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	Perform a manual switch between the protect and working circuits. This statement is honored only if there are no higher-priority reasons to switch.
Options	<p>protect—Request that the circuit become the protect circuit.</p> <p>working—Request that the circuit become the working circuit.</p>
Usage Guidelines	See Configuring SONET/SDH Physical Interface Properties.
Required Privilege Level	<p>interface—To view this statement in the configuration.</p> <p>interface-control—To add this statement to the configuration.</p>
Related Topics	force

