

## rtvbr

---

|                                 |   |
|---------------------------------|---|
| <b>Syntax</b>                   | rtvbr peak <i>rate</i> sustained <i>rate</i> burst <i>length</i> ;  |
| <b>Hierarchy Level</b>          | [edit interfaces <i>interface-name</i> atm-options vpi <i>vpi-identifier</i> shaping],<br>[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> address <i>address</i> family <i>family</i> multipoint-destination <i>address</i> shaping],<br>[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> shaping],<br>[edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> shaping],<br>[edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> address <i>address</i> family <i>family</i> multipoint-destination <i>address</i> shaping]   |
| <b>Release Information</b>      | Statement introduced before JUNOS Release 7.4.  |
| <b>Description</b>              | <p>For ATM2 IQ PICs only, define the real-time variable bandwidth utilization in the traffic-shaping profile.</p> <p>When you configure the real-time bandwidth utilization, you must specify all three options (<b>burst</b>, <b>peak</b>, and <b>sustained</b>). You can specify <b>rate</b> in bits per second either as a complete decimal number or as a decimal number followed by the abbreviation k (1000), m (1,000,000), or g (1,000,000,000). You can also specify <b>rate</b> in cells per second by entering a decimal number followed by the abbreviation c; values expressed in cells per second are converted to bits per second using the formula<br/>1 cps = 384 bps.</p>   |
| <b>Default</b>                  | If the <b>rtvbr</b> statement is not included, bandwidth utilization is unlimited.  |
| <b>Options</b>                  | <p><b>burst <i>length</i></b>—Burst length, in cells. If you set the length to 1, the peak traffic rate is used.<br/><b>Range:</b> 1 through 4000 cells</p> <p><b>peak <i>rate</i></b>—Peak rate, in bits per second or cells per second.<br/><b>Range:</b> For ATM2 IQ OC3 and OC12 interfaces, 33 Kbps through 542,526,792 bps. For ATM2 IQ OC48 interfaces, 33 Kbps through 2,170,107,168 bps. For ATM2 IQ DS3 and E3 interfaces, 33 Kbps through the maximum rate, which depends on the ATM encapsulation and framing you configure. For more information, see Defining the ATM Traffic-Shaping Profile.</p> <p><b>sustained <i>rate</i></b>—Sustained rate, in bps or cps.<br/><b>Range:</b> For ATM2 IQ OC3 and OC12 interfaces, 33 Kbps through 542,526,792 bps. For ATM2 IQ OC48 interfaces, 33 Kbps through 2,170,107,168 bps. For ATM2 IQ DS3 and E3 interfaces, from 33 Kbps through the maximum rate, which depends on the ATM encapsulation and framing you configure. For more information, see Defining the ATM Traffic-Shaping Profile.</p> |
| <b>Usage Guidelines</b>         | See Defining the ATM Traffic-Shaping Profile.   |
| <b>Required Privilege Level</b> | interface—To view this statement in the configuration.<br>interface-control—To add this statement to the configuration.   |

**Related Topics**    cbr, vbr