

## sampling

---

<b>Syntax</b>	<code>sampling <i>direction</i>;</code>
<b>Hierarchy Level</b>	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family inet]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4.
<b>Description</b>	Configure the direction of traffic to be sampled.
<b>Options</b>	<i>direction</i> can be one of the following:  input—Configure at least one expected ingress point.  output—Configure at least one expected egress point.  input output—On a single interface, configure at least one expected ingress point and one expect egress point.
<b>Usage Guidelines</b>	See the <i>JUNOS Services Interfaces Configuration Guide</i> .
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

