

## server

---

<b>Syntax</b>	server;
<b>Hierarchy Level</b>	[edit interfaces pp0 unit <i>logical-unit-number</i> pppoe-options], [edit logical-systems <i>logical-system-name</i> interfaces pp0 unit <i>logical-unit-number</i> pppoe-options]
<b>Release Information</b>	Statement introduced in JUNOS Release 8.5.
<b>Description</b>	Configure the router to operate in the PPPoE server mode. Supported on M120 Multiservice Edge Routers operating as access concentrators.
<b>Usage Guidelines</b>	See Configuring PPPoE.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

