

stop-on-failure

Syntax	stop-on-failure;
Hierarchy Level	[edit access profile <i>profile-name</i> accounting]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches.
Description	Configure authentication order for authentication, authorization, and accounting (AAA) services to send an Acct-Stop message if a supplicant fails AAA authorization, but the RADIUS server grants access. For example, a supplicant might fail AAA authentication due to an internal error such as a timeout.
Default	Not enabled
Required Privilege Level	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Example: Connecting a RADIUS Server for 802.1X to an EX-series Switch■ Configuring 802.1X RADIUS Accounting (CLI Procedure),■ Understanding 802.1X and AAA Accounting on EX-series Switches,

