

system-priority

Syntax	system-priority <i>priority</i> ;
Hierarchy Level	[edit interfaces aeX aggregated-ether-options lacp]
Release Information	Statement introduced in JUNOS Release 9.3.
Description	Define LACP system priority at the aggregated Ethernet interface level. This system priority value takes precedence over a system priority value configured at the global ([edit chassis]) hierarchy level.
Options	<i>priority</i> —Priority for the aggregated Ethernet system. A smaller value indicates a higher priority. Range: 0 through 65535 Default: 127
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

