

tei-option

Syntax	tei-option (first-call power-up);
Hierarchy Level	[edit interfaces br-pim/0/port isdn-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For ISDN interfaces, configure when the Terminal Endpoint Identifier (TEI) negotiates with the ISDN provider.
Options	<p>first-call—Activation does not occur until the call setup is sent.</p> <p>power-up—Activation occurs when the Services Router is powered on.</p> <p>Default: power-up</p>
Usage Guidelines	See Configuring ISDN Physical Interface Properties.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>J-series Services Router Basic LAN and WAN Access Configuration Guide</i>

