

translate-fecn-and-becn

Syntax	(translate-fecn-and-becn no-translate-fecn-and-becn);
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family ccc], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family ccc]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For interfaces with encapsulation type Frame Relay CCC, enable or disable translation of Frame Relay forward explicit congestion notification (FECN) control bits and Frame Relay backward explicit congestion notification (BECN) control bits.
Default	FECN and BECN bit translation is disabled.
Usage Guidelines	See Configuring Frame Relay Control Bit Translation.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

