

transmit-rate

Syntax	transmit-rate (<i>rate</i> percent <i>percentage</i> remainder);
Hierarchy Level	[edit class-of-service schedulers <i>scheduler-name</i>]
Release Information	Statement introduced in JUNOS Release 9.0 for EX-series switches.
Description	Specify the transmit rate or percentage for a scheduler.
Default	If you do not include this statement, the default scheduler transmission rate and buffer size percentages for queues 0 through 7 are 95, 0, 0, 0, 0, 0, 0, and 5 percent.
Options	<p><i>rate</i> —Transmission rate, in bps. You can specify a value in bits per second either as a complete decimal number or as a decimal number followed by the abbreviation k (1000), m (1,000,000), or g (1,000,000,000). Range: 3200 through 160,000,000,000 bps</p> <p>percent <i>percentage</i> —Percentage of transmission capacity. A percentage of zero drops all packets in the queue. Range: 0 through 100 percent</p> <p>remainder—Remaining rate available</p>
Required Privilege Level	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
Related Topics	<ul style="list-style-type: none">■ Example: Configuring CoS on EX-series Switches■ Defining CoS Schedulers (CLI Procedure) or Defining CoS Schedulers (J-Web Procedure)■ Understanding CoS Schedulers

