

unframed

Syntax	(unframed no-unframed);
Hierarchy Level	[edit interfaces <i>interface-name</i> e3-options]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	For E3 IQ interfaces only, enable or disable unframed mode. In unframed mode, the E3 IQ interface do not detect yellow (ylw) or loss-of-frame (lof) alarms.
Default	Unframed mode is disabled.
Usage Guidelines	See Configuring E3 IQ and IQE Unframed Mode.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

