

## use-string

---

<b>Syntax</b>	use-string <i>string</i> ;
<b>Hierarchy Level</b>	[edit ethernet-switching-options secure-access-port vlan (all   <i>vlan-name</i> ) dhcp-option82 remote-id] [edit forwarding-options helpers bootp dhcp-option82 remote-id] [edit forwarding-options helpers bootp interface <i>interface-name</i> dhcp-option82 remote-id]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.3 for EX-series switches.
<b>Description</b>	Use a string rather than the MAC address of the host system (the default) in the remote ID value in the DHCP option 82 information.
<b>Options</b>	<i>string</i> —Character string used as the remote ID value.  <b>Range:</b> 1–255 characters
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Setting Up DHCP Option 82 on an EX-series Switch with No Relay Agent Between Clients and DHCP Server</li><li>■ Example: Setting Up DHCP Option 82 with an EX-series Switch as Relay Agent Between Clients and a DHCP Server</li><li>■ Setting Up DHCP Option 82 on the Switch with No Relay Agent Between Clients and DHCP Server (CLI Procedure)</li><li>■ Setting Up DHCP Option 82 with the Switch as a Relay Agent Between Clients and DHCP Server (CLI Procedure)</li><li>■ [edit forwarding options] Configuration Statement Hierarchy</li><li>■ RFC 3046, <i>DHCP Relay Agent Information Option</i>, at <a href="http://tools.ietf.org/html/rfc3046">http://tools.ietf.org/html/rfc3046</a>.</li></ul>

