

use-vlan-id

Syntax use-vlan-id;

Release Information Statement introduced in JUNOS Release 9.3 for EX-series switches.

Description Use the VLAN ID rather than the VLAN name (the default) in the circuit ID value in the DHCP option 82 information.

Required Privilege Level routing—To view this statement in the configuration.
routing-control—To add this statement to the configuration.

- Related Topics**
- Example: Setting Up DHCP Option 82 on an EX-series Switch with No Relay Agent Between Clients and DHCP Server
 - Example: Setting Up DHCP Option 82 with an EX-series Switch as Relay Agent Between Clients and a DHCP Server
 - Setting Up DHCP Option 82 on the Switch with No Relay Agent Between Clients and DHCP Server (CLI Procedure)
 - Setting Up DHCP Option 82 with the Switch as a Relay Agent Between Clients and DHCP Server (CLI Procedure)
 - [edit forwarding options] Configuration Statement Hierarchy
 - RFC 3046, *DHCP Relay Agent Information Option*, at <http://tools.ietf.org/html/rfc3046>.

