

vlan-id-list

Syntax	vlan-id-list [<i>number number-number</i>];
Hierarchy Level	[edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family bridge], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family bridge]
Release Information	Statement introduced in JUNOS Release 9.2.
Description	Configure a logical interface to forward packets and learn MAC addresses within each bridge domain configured with a VLAN ID that matches a VLAN ID specified in the list. VLAN IDs can be entered individually using a space to separate each ID, entered as an inclusive list separating the starting VLAN ID and ending VLAN ID with a hyphen, or a combination of both.
Options	<i>number number</i> —Individual VLAN IDs separated by a space. <i>number-number</i> —Starting VLAN ID and ending VLAN ID in an inclusive range. Range: 1 through 4095
Usage Guidelines	See Configuring a Logical Interface for Trunk Mode and Configuring the VLAN ID List for a Trunk Interface.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.

