

vtmapping

Syntax	vtmapping (itu-t klm);
Hierarchy Level	[edit interfaces <i>interface-name</i> sonet-options]; [edit chassis fpc <i>number</i> pic <i>number</i>]
Release Information	Statement introduced before JUNOS Release 7.4.
Description	<p>For the Channelized STM1 IQ PIC or Channelized STM1 PIC, configure virtual tributary mapping.</p> <p>For the Channelized STM1 PIC, you configure virtual tributary mapping at the [edit chassis fpc <i>number</i> pic <i>number</i>] hierarchy level.</p>
Options	itu-t—International Telephony Union standard klm—KLM standard Default: klm
Usage Guidelines	See Configuring Channelized STM1 Interfaces.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	<i>JUNOS System Basics Configuration Guide</i>

