

Disabling CoS Shaping-Rate Adjustments for Subscriber Local Loops

To disable hierarchical CoS shaping-rate adjustments for subscriber local loops:

- Disable hierarchical CoS traffic-shaping adjustment by ANCP:
[edit protocols ancp]
user@host# **delete qos-adjust**

Traffic-shaping parameters for all subscriber local loops revert to their current configured values.

Related Topics

- CoS Shaping-Rate Adjustments for Subscriber Local Loops Overview
- Guidelines for Configuring CoS Shaping-Rate Adjustments for Subscriber Local Loops
- Enabling CoS Shaping-Rate Adjustments for Subscriber Local Loops
- Example: Configuring Hierarchical CoS Shaping-Rate Adjustments for Subscriber Local Loops

