

Configuring the Mobile IP Tracing Flags

By default, only important events are logged. You can specify which trace operations are logged by including specific tracing flags. The following table describes the flags that you can include.

Flag	Description
all	Trace all operations
authentication	Trace authentication operations
binding	Trace bindings
event	Trace events
home-agent	Trace home agent operations
interface-database	Trace interface database operations
packet	Trace packet decoding operations
protocol	Trace protocol operations
rtstock	Trace routing socket operations
session-db	Trace session database events
signal	Trace signal operations
subscriber	Trace subscriber events
trace	Trace changes in tracing
tunnel	Trace tunneling operations
user-interface	Trace user interface operations

To configure the flags for the events to be logged:

- Configure the flags.

```
[edit services mobile-ip traceoptions]  
user@host# set flag home-agent
```

- Related Topics**
- Configuring Mobile IP
 - traceoptions

