

## Attaching Dynamic Profiles to PPP Subscriber Interfaces

---

You can attach a dynamic profile to a PPP subscriber interface. When a PPP subscriber logs in, the specified dynamic profile is instantiated and the services defined in the profile are applied to the interface.



**NOTE:** Dynamic profiles are supported only on PPPoE interfaces for this release.

---

To attach a dynamic profile to a PPP subscriber interface:

1. Specify that you want to configure PPP options.

```
[edit interfaces pp0 unit 0]  
user@host# edit ppp-options
```

2. Specify the dynamic profile you want to associate with the interface.

```
[edit interfaces pp0 unit 0 ppp-options]  
user@host# setdynamic-profile vod-profile-50
```

- Related Topics**
- Dynamic Profile Attachment to PPP Subscriber Interfaces Overview
  - Dynamic Profiles Overview
  - Configuring a Basic Dynamic Profile
  - Example: Minimum PPPoE Dynamic Profile

