

Attaching Access Profiles

After you have created the access profile that specifies the subscriber access management authentication and accounting parameters, you attach the profile. Subscriber access management supports access profiles attached at the logical system:routing instance level.

To attach an access profile:

- Specify the access profile.

```
[edit logical-systems logical-system-name routing-instances routing-instance-name]  
user@host# set access-profile vz-bos-metro-fios-basic
```

Related Topics ■ AAA Service Framework Overview

