

Verifying the Scheduling and Shaping Configuration for Subscriber Access

Purpose View the class-of-service (CoS) configurations that are referenced in a dynamic profile for subscriber access.

Action ■ To display the entire CoS configuration, including static and dynamic parameters:

user@host> **show class-of-service**

■ To display the mapping of schedulers to forwarding classes and a summary of scheduler parameters for each entry:

user@host> **show class-of-service scheduler-map**

■ To display traffic shaping and scheduling profiles:

user@host> **show class-of-service traffic-control-profile**

