

## clear dhcp relay binding

---

|                                     |  |
|-------------------------------------|--|
| <b>Syntax</b>                       | clear dhcp relay binding<br><(all   <i>ip-address</i>   <i>mac-address</i> )><br><interface <i>interface-name</i> ><br><logical-system <i>logical-system-name</i> ><br><routing-instance <i>routing-instance-name</i> >  |
| <b>Release Information</b>          | Command introduced in JUNOS Release 8.3.<br>all and interface options added in JUNOS Release 8.4.  |
| <b>Description</b>                  | Clear the binding state of a Dynamic Host Configuration Protocol (DHCP) client from the client table.  |
| <b>Options</b>                      | <p>all—(Optional) Clear the binding state for all DHCP clients.</p> <p>interface <i>interface-name</i>—(Optional) Clear the binding state for DHCP clients on the specified interface.</p> <p><i>ip-address</i>—(Optional) IP address of the DHCP client.</p> <p><i>mac-address</i>—(Optional) MAC address of the DHCP client.</p> <p>logical-system <i>logical-system-name</i>—(Optional) Clear the binding state for DHCP clients on the specified logical system.</p> <p>routing-instance <i>routing-instance-name</i>—(Optional) Clear the binding state for DHCP clients on the specified routing instance.</p> |
| <b>Required Privilege Level</b>     | view   |
| <b>List of Sample Output</b>        | clear dhcp relay binding on page 1<br>clear dhcp relay binding all on page 1<br>clear dhcp relay binding interface on page 2   |
| <b>Output Fields</b>                | For information about output fields, see the show dhcp relay binding command ( <a href="#">Unresolved xref</a> ).  |
| <b>clear dhcp relay binding</b>     | The following sample output displays the address bindings in the DHCP client table before and after the clear dhcp relay binding command is issued.  |
|                                     | <pre>user@host&gt; show dhcp relay binding IP address      Hardware address  Type    Lease expires at 100.20.32.1     90:00:00:01:00:01 active           2007-02-08 16:41:17 EST  user@host&gt; clear dhcp relay binding 100.20.32.1  user@host&gt; show dhcp relay binding</pre>  |
| <b>clear dhcp relay binding all</b> | <pre>user@host&gt; clear dhcp relay binding all</pre>  |

**clear dhcp relay binding**    user@host> **clear dhcp relay binding interface fe-0/0/2**  
**interface**

---

Published: 2009-07-16