

clear virtual-chassis vc-port statistics

Syntax	clear virtual-chassis vc-port statistics <all-members> <interface-name> <local> <member <i>member-id</i> >
Release Information	Command introduced in JUNOS Release 9.0 for EX Series switches. The options all-members and local were added in JUNOS Release 9.3 for EX Series switches.
Description	Clear—reset to zero (0)—the traffic statistics counters on Virtual Chassis ports (VCPs).
Options	<p>none—Clear traffic statistics for the VCPs of all members of a Virtual Chassis configuration.</p> <p>all-members—(Optional) Clear traffic statistics for the VCPs of all members of a Virtual Chassis configuration.</p> <p>interface-name—(Optional) Name of the VCP interface to be cleared of its traffic statistics. Specify either vcp-0 or vcp-1.</p> <p>local—(Optional) Clear VCP traffic statistics from only the switch on which this command is entered.</p> <p>member <i>member-id</i>—(Optional) Clear VCP traffic statistics from only the specified member of a Virtual Chassis configuration.</p>
Required Privilege Level	clear
Related Topics	<ul style="list-style-type: none">■ show virtual-chassis vc-port statistics■ show virtual-chassis vc-port■ Monitoring Virtual Chassis Configuration Status and Statistics■ Understanding Virtual Chassis Components
List of Sample Output	clear virtual-chassis vc-port statistics on page 1 clear virtual-chassis vc-port statistics member 3 on page 1
clear virtual-chassis vc-port statistics	<pre>user@SWA-0> clear virtual-chassis vc-port statistics fpc0: ----- Statistics cleared {master:0}</pre>
clear virtual-chassis vc-port statistics member 3	<pre>user@SWA-0> clear virtual-chassis vc-port statistics member 3</pre>

Cleared statistics on member 3

Published: 2009-07-29