

delete

Syntax delete <*statement-path*> <*identifier*>

Release Information Command introduced before JUNOS Release 7.4.

Description Delete a statement or identifier. All subordinate statements and identifiers contained within the specified statement path are deleted with it.

Deleting a statement or an identifier effectively “unconfigures” or disables the functionality associated with that statement or identifier.

If you do not specify *statement-path* or *identifier*, the entire hierarchy starting at the current hierarchy level is removed.

Options *statement-path*—(Optional) Path to an existing statement or identifier. Include this if the statement or identifier to be deleted is not at the current hierarchy level.

identifier—(Optional) Name of the statement or identifier to delete.

Usage Guidelines See Deleting a Statement from a JUNOS Configuration.

Required Privilege Level configure—To enter configuration mode; other required privilege levels depend on where the statement is located in the configuration hierarchy.

Related Topics deactivate

Published: 2009-07-22