

## request services static-subscribers logout interface

---

<b>Syntax</b>	request services static-subscribers logout interface <i>interface-name</i>
<b>Release Information</b>	Command introduced in JUNOS Release 9.6.
<b>Description</b>	Force static subscriber on the interface to be logged out. No subscriber can subsequently log in on the interface until the interface state is reset by a router reset or the request services static-subscribers login interface command.
<b>Options</b>	interface <i>interface-name</i> —Static interface on which a static subscriber has been created.
<b>Required Privilege Level</b>	view
<b>Related Topics</b>	Forcing a Static Subscriber to Be Logged Out  request services static-subscribers login interface
<b>List of Sample Output</b>	request services static-subscribers logout interface on page 1
<b>Output Fields</b>	When you enter this command, you are provided feedback on the status of your request.
<b>request services static-subscribers logout interface</b>	user@host> request services static-subscribers logout interface ge-2/0/1.5

---

Published: 2009-07-16