

request virtual-chassis recycle

Syntax request virtual-chassis recycle member-id *member-id*

Release Information Command introduced in JUNOS Release 9.0 for EX Series switches.

Description Make a previously used member ID available for reassignment.

When you remove a member switch from the Virtual Chassis configuration, the master reserves that member ID. To make the member ID available for reassignment, you must use this command.



NOTE: You can run this command from the Virtual Chassis master only.

Options member-id *member-id*—Specify the member id that you want to make available for reassignment to a different member switch.

Required Privilege Level system-control

Related Topics ■ request virtual-chassis renumber
 ■ Replacing a Member Switch of a Virtual Chassis Configuration (CLI Procedure)

List of Sample Output request virtual-chassis recycle member-id 3 on page 1

**request virtual-chassis
recycle member-id 3** user@host> request virtual-chassis recycle member-id 3

Published: 2009-07-29