

request virtual-chassis renumber

Syntax request virtual-chassis renumber member-id *old-member-id* new-member-id *new-member-id*

Release Information Command introduced in JUNOS Release 9.0 for EX Series switches.

Description Renumber a member of a Virtual Chassis configuration.



NOTE: You can run this command from the Virtual Chassis master only.

Options member-id *old-member-id*—Specify the ID of the member that you wish to renumber.
new-member-id *new-member-id*—Specify an unassigned member ID (from 0 through 9).

Required Privilege Level system-control

Related Topics ■ request virtual-chassis recycle
 ■ Replacing a Member Switch of a Virtual Chassis Configuration (CLI Procedure)

List of Sample Output request virtual-chassis renumber member-id 5 new-member-id 4 on page 1

**request virtual-chassis
renumber member-id 5
new-member-id 4** user@SWA-0> request virtual-chassis renumber member-id 5 new-member-id 4

Published: 2009-07-29