

active-server-group

Syntax	active-server-group <i>server-group-name</i> ;
Hierarchy Level	[edit forwarding-options dhcp-relay], [edit forwarding-options dhcp-relay group <i>group-name</i>], [edit logical-systems <i>logical-system-name</i> forwarding-options dhcp-relay], [edit logical-systems <i>logical-system-name</i> forwarding-options dhcp-relay group <i>group-name</i>], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay], [edit logical-systems <i>logical-system-name</i> routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay group <i>group-name</i>], [edit routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay], [edit routing-instances <i>routing-instance-name</i> forwarding-options dhcp-relay group <i>group-name</i>]
Release Information	Statement introduced in JUNOS Release 8.3.
Description	<p>Apply a DHCP relay agent configuration to the named group of DHCP server addresses.</p> <p>You can include the active-server-group statement at the [edit forwarding-options dhcp-relay] hierarchy level as a global DHCP relay agent configuration option, or at the [edit forwarding-options dhcp-relay group <i>group-name</i>] hierarchy level as a DHCP relay agent configuration option that applies only to a named group of interfaces.</p> <p>Including the active-server-group statement at the [edit forwarding-options dhcp-relay group <i>group-name</i>] hierarchy level as a group-specific option overrides use of the active-server-group statement at the [edit forwarding-options dhcp-relay] hierarchy level as a global option.</p>
Options	<i>server-group-name</i> —Name of the group of DHCP server addresses to which the DHCP relay agent configuration applies.
Required Privilege Level	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
Related Topics	■ Extended DHCP Relay Agent Overview

Published: 2009-07-16