

## address

---

<b>Syntax</b>	address <i>address</i> ;
<b>Hierarchy Level</b>	[edit dynamic-profiles interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i> ], [edit interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i> ], [edit logical-systems <i>logical-system-name</i> interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i> ], [edit dynamic-profiles <i>profile-name</i> interfaces demux0 unit <i>logical-unit-number</i> family <i>family</i> ]
<b>Release Information</b>	Statement introduced before JUNOS Release 7.4. The [edit dynamic-profiles interfaces <i>interface-name</i> unit <i>logical-unit-number</i> family <i>family</i> ] hierarchy added in JUNOS Release 9.2.
<b>Description</b>	Configure the interface address.
<b>Options</b>	<i>address</i> —Address of the interface.
<b>Required Privilege Level</b>	interface—To view this statement in the configuration. interface-control—To add this statement to the configuration.
<b>Related Topics</b>	■ “Configuring the Protocol Family,” in <i>JUNOS Network Interfaces Configuration Guide</i> . ■ <i>JUNOS System Basics Configuration Guide</i>

---

Published: 2009-07-16