

aggregated-devices

Syntax aggregated-devices {
 ethernet {
 device-count *number*;
 }
 }

Hierarchy Level [edit chassis]

Release Information Statement introduced in JUNOS Release 9.0 for EX Series switches.

Description Configure properties for aggregated devices on the switch.

 The statements are explained separately.

Default Disabled.

Required Privilege Level interface—To view this statement in the configuration.
 interface-control—To add this statement to the configuration.

- Related Topics**
- *JUNOS Network System Basics Configuration Guide* at <http://www.juniper.net/techpubs/software/junos/junos90/index.html>
 - Example: Configuring Aggregated Ethernet High-Speed Uplinks Between a Virtual Chassis Access Switch and a Virtual Chassis Distribution Switch
 - Configuring Aggregated Ethernet Interfaces (CLI Procedure)
 - Understanding Aggregated Ethernet Interfaces and LACP

Published: 2009-07-22