

## authentication-order

---

<b>Syntax</b>	authentication-order [ldap radius   none];
<b>Hierarchy Level</b>	[edit access profile <i>profile-name</i> ]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.0 for EX Series switches.
<b>Description</b>	Configure the order of authentication, authorization, and accounting (AAA) servers to use while sending authentication messages.
<b>Default</b>	Not enabled
<b>Options</b>	ldap—Lightweight Directory Access Protocol.  none—No authentication for specified subscribers.  radius—Remote Authentication Dial-In User Service authentication.
<b>Required Privilege Level</b>	admin—To view this statement in the configuration. admin-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Connecting a RADIUS Server for 802.1X to an EX Series Switch</li><li>■ Configuring 802.1X RADIUS Accounting (CLI Procedure)</li></ul>

---

Published: 2009-07-21