

## bandwidth

---

<b>Syntax</b>	bandwidth <i>bandwidth</i> ;
<b>Hierarchy Level</b>	[edit ethernet-switching-options storm-control interface (all   <i>interface-name</i> )]
<b>Release Information</b>	Statement introduced in JUNOS Release 9.5 for EX Series switches.
<b>Description</b>	For interfaces configured for storm control, configure the storm control level as the bandwidth in kilobits per second of the combined broadcast and unknown unicast streams.
<b>Default</b>	None.
<b>Options</b>	<b>bandwidth</b> —Traffic rate in kilobits per second of the combined broadcast and unknown unicast streams. <b>Range:</b> 100 through 10000000 Kbps <b>Default:</b> None
<b>Required Privilege Level</b>	routing—To view this statement in the configuration. routing-control—To add this statement to the configuration.
<b>Related Topics</b>	<ul style="list-style-type: none"><li>■ Example: Configuring Storm Control to Prevent Network Outages on EX Series Switches</li><li>■ Understanding Storm Control on EX Series Switches</li></ul>

---

Published: 2009-07-22